

6.15 Sealing the Corners on the Door Gasket Frame

Only for HUD/OD/OS 6.10/10.10



Control:

Water drops on the lower corners of the unit because it is not water-tight.



Instruction:

1. Remove the door gasket.
2. Clean both edges of the door gasket frame with alcohol or acetone.
3. Re-seal with silicone E 43 Part No. 700 40 20.



Safety: Important

4. Allow the silicone 24 hours to harden (vulcanisation time) before putting the door gasket back in!

